MATRIX

Turning On & Off The Back Up Beeper

Turning the Matrix **Back Up Beeper** on and off is simple and requires no additional switch.

Press and hold the horn button and the deceleration button at the same time to off the backward sound; or **Back Up Beeper**.

Press and hold the horn button and the acceleration button at the same time to turn on the backward sound; or **Back Up Beeper**.